

NEW


















# Essential equipment for professional electricians: Measure current and voltage with a single instrument!











# Specifications Basic accuracy figures for measurement ranges are indicated in parentheses. Accuracy guaranteed for 1 year, Post-adjustment accuracy guaranteed for 1 year, Product warranty period is 3 years.

	3280-10F	3280-20F		
AC measurement method	MEAN value	True RMS		
Core jaw diameter	ф33 mm (1.30"), jaw thickness: 9.5 mm (0.37")			
Max. rated voltage to earth	Jaw : CAT IV 300 V, CAT III 600 V Voltage measurement terminal : CAT III 300 V, CAT II 600 V			
AC Current	42.00 A/ 420.0 A/ 1000 A (±1.5% rdg.±5 dgt.)			
Frequency characteristics	50 to 60 Hz	40 Hz to 1 kHz		
AC Voltage	4.200 V to 600 V, 4 ranges (±1.8% rdg.±7 dgt.)			
Frequency characteristics	45 Hz to 500 Hz			
DC Voltage	420.0 mV to 600 V, 5 ranges (±1.0% rdg.±3 dgt.)			
Resistance	420.0 Ω to 42.00 MΩ, 6 ranges (±2.0% rdg.±4 dgt.)			
Continuity Check	420.0 $\Omega$ (±2.0% rdg.±4 dgt.) Threshold of buzzer sound 50 $\Omega$ ±40 $\Omega$ or less			
Crest factor	-	2.5 or less (1.5 or less at 4200 counts)		
Display refresh rate	400 ms			

Operating temperature and humidity	-25°C to 65°C (-13°F to 149°F), 80% RH or less (no condensation)				
Storage temperature and humidity	-25°C to 65°C (-13°F to 149°F), 80% RH or less (no condensation)				
Drop-proof distance	1 m onto concrete				
Dustproof and waterproof	IP40				
Standards	Safety : EN 61010, EMC : EN 61326				
Functions	Data hold, Auto power-saving function				
Power supply	Coin type lithium battery CR2032×1				
Continuous use	120 hours	70 hours			
Dimensions and mass	57W×175H×16D mm (2.24"W × 6.89"H × 0.63"D), 100 g (3.5 oz.)				
AC ELEXIBLE CURRENT SENSOR CT6280 specifications					

### φ130 mm (5.12") (Cable cross-section diameter: 5 mm (0.20"); tip Core jaw diameter cap diameter: 7 mm (0.28")) **AC Current** 420.0 A/ 4200 A (±3.0% rdg.±5 dgt.) 40 Hz to 1 kHz

800 mm (31.5")

### Lineup

	AC CLAMP METER 3280-10F	AC CLAMP METER 3280-20F	AC CLAMP METER SET 3280-70F	AC CLAMP METER SET 3280-90F
AC measurement method	MEAN value	True RMS	MEAN value	True RMS
Order code	3280-10F	3280-20F	3280-70F	3280-90F
Includes	3280-10F CARRYING CASE 9398 TEST LEAD L9208 Coin type lithium battery CR2032 Instruction Manual	3280-20F CARRYING CASE 9398 TEST LEAD L9208 Coin type lithium battery CR2032 Instruction Manual	CARRYING CASE C0205 TEST LEAD L9208	3280-20F AC FLEXIBLE CURRENT SENSOR CT6280 CARRYING CASE C0205 TEST LEAD L9208 Coin type lithium battery CR2032 Instruction Manual
Image				

Cable length

### Options

CARRYING CASE 9398 (bundled with the 3280-10F/ 3280-20F)

AC FLEXIBLE CURRENT SENSOR CT6280

(includes C0205, attachment)

CARRYING CASE C0205 (bundled with the 3280-70F/ 3280-90F/ CT6280; fits CT6280, 3280-10F/ 3280-20F, and test leads) TEST LEAD L9208 (bundled Accessory) **TEST LEADS HOLDER 9209 CONTACT PIN SET L4933\*** SMALL ALLIGATOR CLIP SET L4934\*





\*Probe tips can be used on TEST LEAD L9208.

What is the difference between the Mean method and True RMS method? There are two methods for converting current into RMS values: the mean method (mean rectification and the true RMS method (true RMS value indication). Although both methods yield the same value for undistorted sine waves, distortion of the waveform causes the values to diverge.

### **MEAN** method (MEAN value)

The input waveform is treated as an undistorted sine wave (single frequency only). The AC signal mean is calculated, converted to an RMS value, and displayed. rement error increases when the waveform is distorted.

### True RMS method (True RMS)

The waveform including harmonic calculation formula and displayed. onic components is calculated according to an RMS

True RMS measurement yields accurate display values even when measuring a distorted waveform, for example from an inverter-equipped device or switch-

■ Comparing distorted current values from an inverter, etc.

16 A

In fact, this much current s flowing! True RMS method

(3280-20F)

Current waveform from an

Note: Company names and Product names appearing in this catalog are trademarks or registered trademarks of various companies.

DISTRIBUTED BY

(3280-10F)

HIOKI E.E. CORPORATION

### **HEADQUARTERS**

81 Koizumi, Ueda, Nagano, 386-1192, Japan TEL +81-268-28-0562 FAX +81-268-28-0568 http://www.hioki.com/ E-mail: os-com@hioki.co.jp

### HIOKI USA CORPORATION

TEL +1-609-409-9109 FAX +1-609-409-9108 http://www.hiokiusa.com / E-mail: hioki@hiokiusa.com

## HIOKI (Shanghai) SALES & TRADING CO., LTD. TEL +86-21-63910090 FAX +86-21-63910360

http://www.hioki.cn / E-mail: info@hioki.com.cn

### HIOKI INDIA PRIVATE LIMITED

TEL +91-124-6590210 E-mail: hioki@hioki.in

### HIOKI SINGAPORE PTE. LTD.

TEL +65-6634-7677 FAX +65-6634-7477 E-mail: info-sg@hioki.com.sg

## HIOKI KOREA CO., LTD.

TEL +82-2-2183-8847 FAX +82-2-2183-3360 E-mail: info-kr@hioki.co.jp